

KILBY ENTERPRISES

Kit Contents:

- JK-MSP1 Main Skidplate Assembly
- JK-MSP2 Rear Support Plate
- (2) JK-MSP4 Front Supports
- JK-MSP5 Front Upper Support Plate
- JK-MSP-HDW
- (8) 3/8"-16X1
- (8) 3/8" Washers
- (4) 1/2X4" Bolts
- (4) 1/2" Nuts
- (8) 1/2" Washers

This skid plate is designed to work with the OEM muffler as well as factory installed tow hook or 2" receiver. It will also work without the tow hook or receiver. Whether you have the tow hook or the receiver depends on which instructions to follow.



1. No tow hook or receiver

Install the rear mount using the four 1/2" x 4" bolts, flat washers and nuts. Make sure the mount is pushed all the way up and tighten securely.

Factory Tow Hook

Loosen the three factory bolts enough to slide the rear mount into place. Install the spacer for the fourth hole between the rear mount and cross member. Install a 1/2" x 4" bolt, two flat washers and nut. Push the mount all the way up & tighten securely.

Factory Receiver

Loosen the four factory bolts enough to slide the rear mount into place. Push the mount all the way up & tighten.

2. The nut plate needs to be inserted into the frame rail in front of the muffler. Remove the passenger side body mount bolt and slide the nut plate into place. Mount the two front legs keeping the bolts loose.
3. Hold the skid into place and insert the remaining bolts and flat washers. Tighten all hardware securely. Reinstall the body mount bolt. Check for clearances and rattles. Adjust the exhaust mounts if necessary.

Thanks for buying a Kilby Enterprises product!

